


## Joey is Unlinking from Hopper



- 1) Select menu on remote
- 2) On the menu select access settings
- 3) Now select network setup
- 4) Select broadband
- 5) Near the top of the screen select the drop down that says MOCA
- 6) On the remote there is a line of colored buttons, select the blue button to make the screen show the bridging option
- 7) Select off for "Hopper Bridge Support"
- 8) Select save twice
- 9) Unplug all the receivers.
- 10) Plug your Hopper back in
- 11) Once hopper has completed the software download, guide download and has turned programming back on plug in your joey receivers

\*Now you will be able to link the Joey back to the Hopper\*